
## STANDARD MUG PRESS



## STANDARD MUG PRESS HEATING ELEMENTS



- Mini Mug 1.
- 2. Shot Glass
- 3. Water Bottle & 6oz. Mug 6. 17 oz. Latte Mug
- 4. 11 & 15 oz. Mug
- 5. 12 oz. Latte Mug

For use with Standard Mug Press Only (HPN-SIG-MUG)

## GAUGE 1 USAGE MODEL



Turn on the power switch and the display should turn ON. The digital display shows as above.



Press "OK". Use "▲" or "▼" to switch between "C°" or "F°" for your desired reading.

3 HWSquatureSeries

Press "OK" to set the temperature as labeled "SV". Use the arrow keys to select desired temperature.



Press "OK" button to set time. This will be labeled "SV" on the right. Use arrow keys to set desired time.

Press "OK" to enter real time mode. Note that "PV" is short for present value. "SV" is the desired value.



The "COUNTER" on the bottom right shows the number of transfer cycles. It can range from 0 to 999. Press "Reset" for 5 seconds to make counter go to 0.